



## Road Glide/Street Glide Nacelle Air Ride Rocker Switches

### **Air Ride (3 Wire)**

Red is power

Yellow and Green are Up and Down

### **Center Stand (6 wire)**

Red is power

Black is ground

Tie Both Orange Together

Tie Both Brown Together

Brown and Orange go to Center Stand Actuator